

Infeed Support Arms

These measurements are for my SawStop PCS table saw with the industrial mobile base. All pieces are 3/4" thick stock. However, size the thickness of the arm to be flush with the top of the saw, or slightly lower. Drill a 1" hole at the end for easy hanging. A small hinge of some kind is needed for the leg connection. These are my exact measurements. Adjust accordingly to your saw.

1. Secure the leg to the arm with a hinge leaving a few inches behind the leg.
2. Clamp the plane wing shaped piece to the front of the rail.
3. Secure the small block to the end of the arm and insert the small block between the rail and the saw.
4. Pull the arm back while securing it to the wing piece for a tight fit around the rail.
5. Store them conveniently so you are more inclined to use them.

